



BONDED WELL

with



	OMEGA N55 Adhesive	OMEGA QUILLI Sealing Compound	UNI MS Sealant-Adhesive (gaps)	AIRSTOP SPRINT Sealant	OMEGA FROZEN Adhesive Paste	AIRSTOP FLEX Adhesive Tape	AIRSTOP KB Adhesive Tape	OMEGA UVKB Facade Tape	AIRSTOP SOLO	AIRSTOP ELASTO	AIRSTOP ULTRA Adhesive Tape	AIRSTOP Conduit Sleeves	BUTYL Stretch Flex	OMEGA DB Sealing Tape	AIRSTOP BB Bitumen-rubber Tape	OMEGA PLASTO Butyl-rubber Tape	OMEGA Alu-Butyl Conduit Sleeve
OMEGA Roof Sheeting (125-330 g/m ²)		✓ ^B			✓	✓					✓					✓	✓ ^B
OMEGA UDOs 330 TopGrip Roof Underlay	✓																✓ ^A
OMEGA WD Wind Seal		✓		✓	✓	✓											✓ ^B
OMEGA G20 G50 Fassade Lining	✓				✓ ^C			✓									
AIRSTOP SD18 Vapour Barrier				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
OMEGA SD10 Vapour Barrier		✓ ^B		✓	✓	✓	✓				✓	✓	✓	✓	✓	✓	✓ ^B
FH FORTE Fleece Vapour Barrier				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
ÖKO NATUR Vapour Barrier				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
AIRSTOP VAP Vapour Retarder				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
AIRSTOP DIVA+ Vapour Barrier fabric reinforced				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
TIMBER Protect SK			✓		✓	X	X	X	X	X	X	X	X	X	X	✓	✓
TIMBERTEX Vapour Retarder				✓	✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
AIRSTOP 1500 Vapour Barrier					✓	✓	✓	X	✓	✓	✓	✓	✓	✓	✓	✓	X
Cladseal EPDM					✓												

Wood / Wood-based Materials

Rough sawn wood	✓	✓	✓	✓	✓	✓ ^A											
Planed wood	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
OSB	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Particle board	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
MDF	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Plywood	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Softwood fibre		✓	✓	✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A

Mineral Construction Materials

Raw brick	✓		✓	✓	✓	✓ ^A	X	X	X	X	X		X	X	X	✓ ^A	✓ ^A
Sand-lime brick / Brick + finish	✓		✓	✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A
Concrete	✓		✓	✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A
Plasters	✓		✓	✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A
Clay				✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A
Gypsum	✓			✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A
Gypsum fibreboard	✓			✓	✓	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A	✓ ^A

Membranes

Paper				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PE				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Polyamide				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PP smooth				✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
PP fleece/fabric-like		✓ ^B		✓	✓	✓	X	X	X	X	X	X				✓	✓ ^B

Other materials

Hard PVC			✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Bitumen													✓ ^A , ✓ ^B	✓ ^B	✓	✓	✓ ^A , ✓ ^B
Metal	✓		✓		✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓

A If necessary with UNI XL / Spray or BUBI LF Primer | **B** Heat = enables adhesion | **C** On back only | **X** Recommended under certain conditions

ⓘ A primer may be required for all combinations if the substrate has inadequate bearing capacity.