



Technical data sheet

AIRSTOP FLEX FEE Adhesive Tape

To ensure the air and wind-tightness of a building's shell the membranes or sheeting materials used must be permanently sealed at overlaps, gaps, joins and penetrations areas. AIRSTOP FLEX FEE Adhesive Tape is flexible, tear-resistant, can be plastered over and painted over and has a high adhesive content with a highperformance adhesive. The adhesive tape's backing with separate liners means that the tape is particularly suitable for adhesion at corners, intersections and for window installation conforming to RAL and ÖNORM B 5320.

ADVANTAGES

- Förderbar entsprechend QNG Kriterien

FIELD OF APPLICATION

- corner adhesion and material intersections
- a seal for building joints (window)

AVAILABLE DIMENSIONS

Article number	Roll width	Roll length	Split liner	Carton
3AFLEX60G	60 mm	25 m	12 / 48	8 rolls

TECHNICAL DATA

sd-value	5 m	Material composition	Flexible fleece, laminated air-tight
Temperature resistance	-40–80 °C	Working temperature	-5–40 °C
Shelf life	2 years	Colour	Transparent white with green AIRSTOP imprint
UV-resistance	2 months	Storage	Cool and dry

AIRSTOP FLEX FEE Adhesive Tape

INFO

AIRSTOP FLEX FEE is attached to the window frame after the window has been installed. The fleece side of the tape can be plastered over and painted over. The self-adhesive side is fixed to the wall, wood, OSB or vapour barrier (if necessary pre-treat surfaces with BUBI LF Adhesive Primer). The materials used must be free from dust and grease and substrates must be dry and supporting.

(1) CUTTING TO SIZE AND ADHESION

Cut AIRSTOP FLEX FEE Adhesive Tape with approx. 12 cm excess length. Pull the narrow backing paper off the tape and attach the tape carefully to the window frame.

(2) CORNER FITTING

At the corners cut into the adhesive tape with a cutter and attach round the corner. If the tape does not fit firmly in the corner it can be re-finished using UNI MS Sealant Adhesive or AIRSTOP SPRINT Sealant .

(3) WORK AROUND THE WINDOW

Now continue to press the window tape onto the window frame. Fit each corner as described under 2).

(4) PULL OFF THE WIDE LINER AND SECURE

When the window tape has been attached all around the window frame and the gap sealed, pull off the wide backing paper and press on the tape. The higher the pressure, the better the adhesion (AIRSTOP ROLL Pressing Roller, AIRSTOP RAK Plastic Squeegee)!

